RadioShack™

Cat. No. 60-1152

Wire-Controlled Hot Wheels® Street Sharks™

INSTALLING BATTERIES

Your *Street Sharks* requires two AA batteries (not supplied). We recommend alkaline batteries (such as Cat. No. 23-557).

Illus

1. Slide off the battery compartment cover in the direction of the arrow.
2. Install two fresh batteries. Match the polarity marks (+ and –) inside the compartment.
3. Replace the cover.

Replace the batteries if the *Street Sharks* moves slowly or stops. Remove the batteries if you do not plan to use the *Street Sharks* for several days.

Cautions:

- Use only fresh batteries of the required size and type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- Never leave dead or weak batteries in the *Street Sharks*.
- Dispose of batteries properly; do not bury or burn them.

OPERATION

Caution: Never play with your *Street Sharks* in the street.

To make the *Street Sharks* go in a straight line, press and hold down s on the controller.

Or, to make it back up and turn to the left, press and hold down t on the controller.

Illus

© 1996 Tandy Corporation.
All Rights Reserved.
RadioShack is a trademark used by Tandy Corporation.
Hot Wheels is a registered trademark of Street Wise Designs, Inc.
Street Sharks is a trademark of Street Wise Designs, Inc.

Note: Your *Street Sharks* stops when it runs into anything, but the motor keeps running. When this happens, press the opposite direction button so the *Street Sharks* can change direction, or move the *Street Sharks* by hand.

CARE AND MAINTENANCE

Your Wire-Controlled Hot Wheels *Street Sharks* is an example of superior design and craftsmanship.

Follow these hints to enjoy your *Street Sharks* for a long time:

- Keep it out of dirt and water.
- Don't drive it on thick carpet.
- Clean it with a damp cloth to keep it looking good.
- Don't take it apart! If something is wrong with it, take it to your local RadioShack store for help.

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

5A6 Printed in China

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

5A6

Printed in China

RadioShack Limited Warranty
FOR RADIO CONTROLLED VEHICLES

This product is warranted against defects for 90 days from date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. Within this period, we will repair it without charge for parts and labor. Simply **bring your RadioShack sales slip** as proof of purchase date to any RadioShack store. This warranty does not cover transportation costs. Nor does it cover a product subjected to misuse, accidental damage, crash, collision or any other damage relating to impact or violent contact.

EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

We Service What We Sell *10/95*

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

5A6 Printed in China